

Instructions for wearing PANASONIC thermoluminescent dosimeters (TLDs)

Wear the dosimeter on the chest. Always wear the dosimeter when working!

Attachment is achieved with the metal clip. Return the worn dosimeters without the metal clips. Attach the clips of the dosimeters you are about to wear.

After work and during leave periods, keep the dosimeters:

- outside of the nuclear facility
- away from radiation sources
- safe from extreme heat sources.

The dosimeter bags have different colors for every month, for ease of periodically changing the dosimeters.

Do not tamper with the dosimeter in any way!

WHAT HAPPENS IF PANASONIC DOSIMETERS ARE LOST?

If Panasonic dosimeters are intentionally lost or physically damaged, a 100-RON fee will be perceived for each Panasonic TLD lost or physically damaged.

WHEN IS A DOSIMETER CONSIDERED TO BE LOST?

A Panasonic dosimeter is considered lost if it was not returned to our laboratory within 60 days from the end of the period for which it was assigned for wearing.

Example: A dosimeter was sent to be worn in January 2014. It is worn in the period 01-31.01.2014. If the dosimeter does not arrive at the laboratory by 15.04.2014, it is considered lost and the 100 RON loss fee/dosimeter must be paid.

DOZIMED, Individual Dosimetry Laboratory, Calea Vacaresti, No. 391, Sun Offices, Sector 4, Bucharest
Tel/Fax: 021/457.42.62, 021/457.46.04, 021/457.46.05, e-mail:office@dozimed.ro,
web:www.dozimed.ro