

S.C. DOZIMED S.R.L.

DOSIMETRIC MONITORING SERVICES

PANASONIC THERMOLUMINESCENT DOSIMETERS

ASR no. MG 2510/2012

Modern technology, used in most European individual dosimetry laboratories. Thermoluminescent dosimeters are currently used in most EU countries for individual dosimetric monitoring.

The detectors are made of tissue equivalent material: the thermoluminescent crystals used (LiB407) have Z_{effectiv} close to the human tissue which leads to a significant improvement in personal equivalent dose ratings.

Detector type: - 2 elements: Li2B4O7: With phosphorus equivalent tissue;

- 2 elements CaSO4: Highly-sensitive Tm phosphorus

Easy use of dosimeters:

- The thermoluminescent dosimeters represent a unitary system, composed of 4 thermoluminescent crystals embedded in a special cassette. The analysis of the 4 detectors provides information about average energy and irradiation angle.
- Very low dose values can be determined: minimum detection limit of the thermoluminescent system is much lower (by 40 - 70%, depending on the field of use) than that of the film dosimeter. The possibility to determine very low doses, starting at 0.03 mSv, leads to a reduction in cumulated doses over one year.
- Increased accuracy of measurements made, due to much lower energy dependence of the response of the thermoluminescent dosimeter compared to film badge (up to 20% for thermoluminescent dosimeters, compared to about 2000% for film dosimeters!)
- The information is read and deleted within a single readout-deletion cycle, by passing through the reader only once. There is no risk that the dosimeter is sent to the customer without deleting the previously gathered information.
- Different colors for consecutive months: thermoluminescent dosimeters are sealed in special bags, labeled with the name of the occupationally exposed individual and the unique identifier of the dosimeter.
- Elimination of the risk of contamination of dosimeters: sealing dosimeters leads to avoidance of contamination with various radioactive substances (in the case of nuclear medicine laboratories or research laboratories), dust, chemicals, etc.